

Computational Reconfigurable Imaging Spectrometer (CRISP)

**Adam Milstein, Ryan Sullenberger, Charles Wynn, Yaron Rachlin,
Corrie Smeaton, Phil Chapnik, Steven Leman**

ACT-17

Earth Science Technology Forum

June 25, 2020

DISTRIBUTION STATEMENT A. Approved for public release. Distribution is unlimited.


This material is based upon work supported by the National Aeronautics and Space Administration under Air Force Contract No. FA8702-15-D-0001. Any opinions, findings, conclusions or recommendations expressed in this material are those of the author(s) and do not necessarily reflect the views of the National Aeronautics and Space Administration .

© 2020 Massachusetts Institute of Technology.

MIT Proprietary, Subject to FAR52.227-11 Patent Rights - Ownership by the contractor (May 2014)

Delivered to the U.S. Government with Unlimited Rights, as defined in DFARS Part 252.227-7013 or 7014 (Feb 2014). Notwithstanding any copyright notice, U.S. Government rights in this work are defined by DFARS 252.227-7013 or DFARS 252.227-7014 as detailed above. Use of this work other than as specifically authorized by the U.S. Government may violate any copyrights that exist in this work.


 **LINCOLN LABORATORY**
MASSACHUSETTS INSTITUTE OF TECHNOLOGY




ESTO
Earth Science Technology Office



Earth Observation Technology: Traditional Approach



NASA's Aqua Satellite (2002-present)




NASA's Atmospheric Infrared Sounder (AIRS) instrument

- Expensive (~\$2B/satellite), and heavy (~2000 kg)
- Long development cycle (~10 yrs plus >10 yrs of operation)
- High consequences of failure



Our Approach: Computational Reconfigurable Imaging Spectrometer (CRISP)




- Uses static mask and scan/platform motion to encode spectral data cube
- Sensitivity advantages over traditional designs, enabling smaller infrared instruments that use uncooled thermal detectors




Proposed Operating Modes: Varying Area Coverage Rate


Drift Scan Mode



Wide Area Mode



Long Dwell Mode





- **Example scenario: Cued Cubesat constellation**
 - First sat identifies interesting phenomenon during wide area search
 - Second sat cued to look more closely with long-dwell mode
- **CRISP concept allows flexible operation, based on mission-specific requirements for area coverage, spatial/spectral resolution, and sensitivity**



Breadboard Measurements

λ	7.7 μm – 14 μm (67 pixel dispersion extent)
$\Delta\lambda$	0.14 μm resolvable
D	5 cm
FOV	$\sim 15^\circ$
<ul style="list-style-type: none">• COTS f/1 camera lenses from FLIR• Custom ZnSe prisms• Custom designed mounts and baffles• Uncooled microbolometer	


- Use breadboard to validate model predictions
- Ruggedized breadboard used in flight test






Lab Measurements: Spectra for Extended and Narrowband Sources, and Trace Gas


Blackbody Source



Narrowband Sources



Transmission Through Absorbing Gas




Breadboard measurements agree with predictions for broadband, narrowband, and trace gas absorption




Lab Measurements: Fast Scan with Motion Blur Removal


Point Source Motion Blur: Cross Section



Point Source Motion Blur: Raw Measurements




CRISP Inversion of Motion Blur



- Modulation from CRISP can be used to invert motion blur
- Maintains image quality even with low frame rates




Flight Measurements: Initial Tests




CRISP demonstrated on real moving platform, with irregular motion



Flight Measurements: Coastal Crossing and TES




Spectral Data Cube



CRISP spectra agree with prediction for sand and water, and can support Temperature Emissivity Separation (TES)



Flight Measurements: Trace Gas Detection




CRISP successfully detected a trace gas release




CRISP: Summary and Future Plans

- We have validated key model predictions for CRISP in the lab and demonstrated spectral imaging in flight
- Current emphasis is on developing scan and spectral resolution modes and identifying performance limits
- We are currently proposing a brassboard instrument demo that would aim to meet future Landsat thermal IR band requirements
- Surface Biology and Geology and Planetary Boundary Layer mission concepts also being investigated

Landsat 8 Thermal Imagery
Paluweh volcano, Indonesia, April 2013



**Proposed Brassboard Lens
Barrel Design**







BACKUP



SNR of CRISP vs. SNR of Conventional Slit-Based Spectrometers



Example:
 $M = 1920$ imager rows
 $N_\lambda = 30$ wavelengths


	Slit-based system SNR scaling	CRISP SNR scaling	Rationale
Background-noise limited (e.g., visible CCD, cooled MCT)	1	$\sim \sqrt{M/2N_\lambda}$ Example*: $\sim 6\times$	CRISP is overdetermined: $M \gg N_\lambda$
Detector-noise limited (e.g., uncooled microbolometer)	1	$\sim \sqrt{M}/2$ Example*: $\sim 22\times$	Additional “multiplex” advantage when all λ measured at once

CRISP enables significant SNR improvement over conventional designs due to measurement count and wavelength multiplexing




Lab Measurements: Fast Scan with Motion Blur Removal


Point Source Motion Blur: Cross Section



Point Source Motion Blur: Raw Measurements




CRISP Inversion of Motion Blur



- Modulation from CRISP can be used to invert motion blur
- Maintains image quality even with very fast scans relative to frame rate



Flight Measurements: Initial Tests



CRISP demonstrated on real moving platform, with irregular motion